

Instructions for Operating AspenAir's Working Sales Demo

- 1 - While the unit is still unplugged, open the front grid
- 2 - Remove the fiberglass media and set it aside
- 3 - Pour about one quarter to one third of the baggy of shipping popcorn into the area where the media once resided
- 4 - Shake the demo unit from side to side until the popcorn is widely scattered
- 5 - Plug in the sales demo
- 6 - Holding the sales demo from the outer edges, turn the unit on
- 7 - The popcorn should become very active; bouncing around and up and down, eventually attaching themselves to each other (this simulates the process of agglomeration within our high voltage polarization chamber)
- 8 - Turn the unit off to allow the energy to discharge, then shake the unit from side to side until the popcorn is widely scattered again, then turn it on
- 9 - To demonstrate how safe it is, you may touch one or both grids while it's running, or stick a pen or screwdriver through both grids. Be careful not to break the grids!
- 10 - We're demonstrating how particulates react within our polarization chamber, while also showing that it's perfectly safe to be handled, due to its low amperage (8 milliamps)
- 11 - When you're finished, simply place the media back inside the polarization chamber (with the popcorn), or you may return the popcorn to the plastic baggy.
- 12 - Return the demo to its box / package for safe keeping

If you have any questions, or suspect that your Sales demo is not working properly, please call 1-888-326-0976, ext 1

